



An ISO 9001:2008 Company

LOOP CALIBRATOR Model KM-CAL-805

GENERAL SPECIFICATIONS

- * **Basic Accuracy** : $\pm 0.05\%$
- * **Display** : 4 Digit LCD display.
- * **Max. Allowable Voltage** : 30V..
- * **Operating Temperature Range** : 0 ~ 50°C.
Humidity range : $\leq 80\%$ RH
- * **Storage Temperature Range** : $\leq -10^\circ\text{C} \sim 50^\circ\text{C}$
Humidity range : $\leq 90\%$ RH
- * **Temperature Coefficient** : $0.1 \times (\text{designated Accuracy}) \% / ^\circ\text{C}$ (5°C ~ 18°C, 28°C ~ 40°C)
- * **Power** : 1.5V x 2 alkaline batteries.
- * **Power Consumption** : about 400mA / 3V in condition of 10mA with 1k Ω load.
- * **Dimension** : 180 (L) x 90 (W) x 47 (D) mm (with holster)
- * **Weight** : About 500g

SAFETY :

Complies with IEC1010 (safety standard issued by International Electrician Committee)

ACCESSORIES :

User Manual, Test lead CF-36, (Clips for probe), Holster & Carrying case.



Preliminary Data

ELECTRICAL SPECIFICATIONS - KM-CAL-805

OUTPUT FUNCTION

Output	Range	Output Range	Resolution	Accuracy	Remarks
DC Current	20 mA	0.000 ~ 22.000mA	0.001mA	$\pm 0.05\%$ set value + 4 μA	Max. load 1K Ω at 20mA
Simu-transmitter (absorption Current)	-20 mA	0.000 ~ -22.000mA	0.001mA	$\pm 0.05\%$ set value + 4 μA	Max. load 1K Ω at 20mA Note: power supply range : 5 ~ 25VDC
Loop Power	24 V			$\pm 10\%$	Max. Output current upto 25mA

INPUT FUNCTION

Input	Range	Output Range	Resolution	Accuracy	Remarks
Voltage	28 V	-0.200 ~ 28.000V	1mV	$\pm 0.02\%$ reading $\pm 2\text{mV}$	Input Resistance about 1M Ω
Current	20 mA	-1.000 ~ 22.000mA	0.001mA	$\pm 0.02\%$ reading $\pm 4\mu\text{A}$	Resistance about 20 Ω
Loop Current	20 mA	0.000 ~ 22.000mA	0.001mA	$\pm 0.02\%$ reading $\pm 4\mu\text{A}$	Providing 24V Loop Power

All Specifications are subject to change without prior notice.



G-17, Bharat Industrial Estate, T. J. Road, Sewree (W), Mumbai - 400 015. INDIA.
Sales Direct.: 022-24156638, **Tel. :** 022-24124540, 24181649, **Fax :** 022-24149659
Email : kusam_meco@vsnl.net, **Website :** www.kusamelectrical.com

LIST OF PRODUCTS

- * Digital Multimeter
- * AC Clamp Adaptor
- * Thermo Anemometer
- * Distance Meter
- * Network Cable Tester
- * Earth Resistance Tester
- * DC Power Supplies
- * Calibrators
- * Frequency Counter
- * Phasing Sticks
- * Waterproof Pen Testers
- * EMF Detector
- * Wood, Paper & Grain Moisture Meter
- * Transistorised Electronic Analog & Digital Insulation Resistance Testers(upto 10 KV)
- * Digital Sound Level Meter & Sound Level Calibrator
- * Digital contact & Non-contact Type Tachometer
- * Digital Non-contact (infrared) Thermometer
- * Maximum Demand Controller/Digital Power Meter
- * Digital Hand Held Temperature Indicators
- * Digital AC & AC/DC Clampmeter
- * AC/DC Current Adaptor
- * Thermo Hygrometer
- * Digital Lux Meter
- * Power Factor Regulator
- * Digital Panel Meters
- * High Voltage Detector
- * Gas Analysers
- * Function Generator
- * Battery Tester
- * Solar Power Meter



G 17, Bharat Industrial Estate, T. J. Road,
Sewree (W), Mumbai - 400 015. INDIA.

Sales Direct : (022) 24156638

Tel. : (022) 24124540, 24181649. **Fax :** (022) 24149659

Email : kusam_meco@vsnl.net

Website : www.kusamelectrical.com
www.kusam-meco.co.in



AN ISO 9001:2008 COMPANY

LOOP CALIBRATOR

MODEL - KM -CAL 805

OPERATION MANUAL

TABLE OF CONTENTS

TITLE	PAGE NO.
I. Safaety Information.....	01
II. Instrument Panel Layout and Functions..	2-3
III. Instrument Maintenance.....	4-5
IV. Power on / off of Instrument.....	6-7
V. Output from Instrument.....	8-11
VI. Instrument Measurement.....	12-15
VII. Performance Index.....	16-17
VIII. Notice of the Manual.....	18-23
IX. Test certificate.....	24
IX. Warranty.....	25

Section One Safety Information

To ensure the safety operation, the following signs are used only as specified in this operation instruction:

△ Warning A warning shows that if the operation does not comply with the following correct instruction is possible to bring hazards to the user or cause damage to the instrument in use, The warning also point out how to avoid the accidents.

△ Caution A caution shows that if the operation does not comply with the following correct instruction, it is possible to cause damage to the instrument, it is use. The caution also points out how to avoid mal-operation.

△ Note A note serves as a sign to remind the user that is must understand the correct operation of the instrument and its characteristics.

To prevent the user and the Instrument from any electric shock and other hazards, it is necessary to observe the following regulation.

△ Warning

- It is not allowed to operate the Instrument the working field where there exists flammable gas or explosive gas or vapor, It is very gangrenous to operate the instrument in such a surrounding.

between any terminal and earth ground.

⚠ Caution

- No one is allowed to remove the spit case of the Instrument except professionals.
- Periodically wipe the case with a damp cloth and detergent do not use any corrosive solvents.

⚠ Note

- To keep the Instrument in a designed accuracy, it needs warming up 5 minutes before it is put into operation.
- If any user requires a higher accuracy of the calibrator, he or she is requested to make contact with the manufacturer or our product distributors.

Section Two Instrument Panel Layout and Functions




Illustration of LCD Display Area



OUTPUT: Press the key (OUTPUT / IN / SW) when the symbol **OUTPUT** appears. it denotes that the Instrument is in a state of output.

INPUT: Press the key (OUTPUT / IN / SW) when the symbol **INPUT** appears, it denotes that the Instrument is in a state of input.

CAL : When the symbol **CAL** appears, denotes that the Instrument is in a state of calibration.

0 FS : When the symbol 'O' OR 'FS' appears during the calibration, it denotes that the zero point or the full scale point is being calibrated.

Battery icon : When this symbol appears, it denotes that the battery is nearly used up and needs replacing.

▲ : When this symbol appears, it denotes that the output digits need setting

V. mA . % : These symbols denote the units of both present input and output values.

ON **OFF** : These symbols denote the turn- on or turn-off of any input / output signals.

---- : These symbols denote the high and low speed auto-ramp, auto-step ramp.

Section Three Instrument Maintenance

This section provides some basic maintenance procedures. Repair calibration, and servicing not covered in this manual must be performed by qualified personnel For maintenance procedures not described in this manual, contact a Service Center.

General Maintenance

Periodically wipe the case with a damp cloth and detergent; do not use abrasives or solvents.

- Take out the batteries if the Instrument will not be used for a long time.
- Dirt or moisture in the terminals can affect readings.

Clean the terminals as follows:

- 1) Turn the Instrument off and remove all test lead.
- 2) Shake out any dirt that may be in terminals.
- 3) Soak a new swab with alcohol. Clean each terminal with the swab.

Replacing the Batteries

This Instrument is powered by two AA batteries (IECLR6)

⚠ Warning

To avoid electrical shock or personal injury:

- Remove Test Leads from the Instrument before opening the battery door.
- Close and latch the Battery Cover before using the meter.

⚠ Note

- The new and old Batteries cannot be mixed.
- Make sure the battery's odes are in accordance with the marks illustrated in battery pool when replacing them.
- Take out the batteries if the meter will not be used for a long time.
- Dispose the old batteries in accordance with the local law.

Replace the batteries as follows. (See Figure 3-1):

- 1) Turn off the Instrument and remove all test Leads from the Terminals;
- 2) Take off the protector of the Instrument; remove the battery cover by using a standard-blade screwdriver to turn the battery case;
- 3) Replace with two new batteries;
- 4) Reinstall the battery case and tighten screws.




Figure 3-1 Replacing batteries

Replacing Fuse

⚠ Warning

To avoid personnel injury or damage to the meter, use only the specified fuse. the specification is 63mA 250V fast-melt.

Replace the fuse as follows (Refer to Figure 3-2 if necessary):

- 1) Remove the test leads from the meter and turn the meter OFF;
- 2) Take off the protector of the meter, remove the four screws by using a standard-blade screwdriver, and then take off the cover;
- 3) Replace the blown fuse(s);
- 4) Reinstall the cover;
- 5) Reinstall the meter's protector.




Figure 3-2 Replacing fuse

Section Four Power-on/off of Instrument power on/off

Press the power key to turn on the power supply of the Instrument. Then repress it to hold it in one second and the power will be off.

When the power is turned on, the Instrument start to make self-diagnosis internally and the full screen is in display. After this, appropriate operation should be carried out.

⚠ Note

To ensure correct operation of the Instrument, it is recommended to turn off the power pausing 5 seconds and then restart the Instrument.

Automatic Power-off

The factory default setting is that the Instrument will cut off the power automatically if no operation applied to the Instrument within 15 minutes.

Users can decide whether they want to use this function or not.(See Section 7 for inference)

Section Five Output from Instrument

The Instrument produces the DC current from its appropriate output terminal (OUTPUT) set by the user or simulating a transmitter.

⚠ Caution

Do not apply voltage to the output terminal during the operation. if any improper voltage is applied to the output terminal. it will cause damage to the internal circuit.

Output Operation Procedure

Function Operation	% Operation	Display	Setting Range
DCI 20mA	20mA : %	00.000mA -025.00 mA%	00.000~22.000 mA -025.00~110.50 mA%

Current Output

1) Insert one end of the test leads to the + mA - output jack (OUTPUT) of the Instrument and connect the other end with the input of the user's Instrument as shown in Figure 5-1:




Figure 5-1

2) Press the key (OUTPUT/IN) , and OUTPUT appears in the display. it denotes that the Instrument is in an output state;

3) Press the key (mA%/V) ,to select the output to be set in 'mA' OR % and then the unit mA or mA% appears, in which 0% denotes 4mA; 100% denotes 20mA;

4) Press the key (◀) / (▶) to select the set digits of the output;

5) Press the key (▲) / (▼) to change the value of the set digits. the value can do carry or number decrement automatically. Hold the pressed key in one second and the numerical value will keep varying.

25% Step Current Output

1) Connect to the Instrument as shown in Figure 5-1;

2) When the key (OUTPUT) is pressed, the OUTPUT appears in the LCD, it denotes the Instrument is in an output state.

3) Press the key (25%/RAMP) and th symbols 'r' and '▲' will appear.

4) Press the key (mA% / V) to select the output to be set in mA or % and then the unit 'mA' or 'mA%' appears;

5) Press the key (▲) / (▼) to change the output in a value of 25%, in which 0% denotes 4mA and 100% denotes 20mA;

6) Reprress the key (25%/RAMP) so as to exit the step current output.

Current Output Set for Zero Point & Full Scale

1) Connect to the Instrument as shown in Figure 5-1;

2) When the (OUTPUT/IN) key is pressed the OUTPUT appears in the LCD, it denotes the Instrument is in an output state;

3) Press the key (100%/START) and the symbols 'r' '▲' '0' 'FS' will appear in the display;

- 4) Press the key (▲) to be set to 100% and the current output will be 20mA Press the key (▼) to be set to 0% and the current output will be 4mA.
- 5) Repress the key (100%/START) so as to exit the step current output.

Auto-ramp Output

- 1) Connect as shown in Figure5-1;
- 2) When the key (OUTPUT) is pressed the **OUTPUT** appears in the LCD, it denotes the Instrument is in an output state;
- 3) When the key (STEP/AUTO) is pressed, the symbols 'OUTPUT OFF/AS' along with '4mA' appear in the LCD. If so, it denotes that the Instrument is getting into the mode of RAMP;
- 4) Repress the key (25%/RAMP) again so as to change the type of the output ramp, which finds itself in the lower left of the LCD. The type appears with 'Λ S' 'Λ F'. in proper order. These symbols denote a low speed ramp and a high speed ramp respectively. The former is set to a cycle up to 60S and the latter is up to 30S, while the auto-stair step ramp pauses 5 seconds at each step;
- 5) Press the key (100%/START) to start the output of the set waveform when the symbol 'ON' appears, Now repress the key (100%/START) again and the output will pause on a current value and the symbol 'OFF' will appear. Then press the same key again and output will continue to do the set steps from the pause value. When the symbol 'OFF' appears, press any one of the keys (▲), (▼), (◀), (▶) so as to bring the output back to the 0% Then the value of 4mA appears in the display.

Simulating Transmitter Output (XMT)

- 1) Insert one end of the test lead to the 'XMT' output jack of the Instrument and connect the other end with the input terminal of the user's device as shown in the Figure 5-2;




Figure 5-2

- 2) The key-operation is the same as that of the current output.

△ Note

- Range of power supply 5 to 25VDC.
- Usage : during the operation of the current output, use the external 24VDC power supply in a mode of connecting a transmitter, thus being able to prolong the working life of the battery.

Section Six Instrument Measurement

⚠ Warning

During the operation, never apply more than 30V between any two terminals, or between any terminal and earth ground. Any voltage more than 30V will not only do damage to the Instrument but also lead to possible personal injury.

⚠ Caution

- During the operation, never apply more than 30V between any two terminal, or between any terminal and earth ground. Any voltage more than 30V will not only do damage to the Instrument. but also lead to possible personal injury.
- When connecting to the Instrument, the power supply of the device under test should be cut off. Otherwise, any connection with a device without cutting off its power supply will cause possible damage to the Instrument.

Input Operation Procedure

Function Operation n	% Operation	Display	Measurement Range
DCI 20mA	20mA	00.000mA	-1.000~22.000 mA
DCV 28 V	%	-025.00 mA%	-31.25~112.50 mA%
		0.000 V	-0.2000~28.000 v

Measuring DC Current

- 1) Insert one end of the test lead into the mA jack of the Instrument (INPUT) terminal and connect the other end to the output of the user's device as shown in Figure 5-3;




Figure 5-3

- 2) Press the key (OUTPUT / IN), the LCD displays 'INPUT' and it denotes that the Instrument is in an input state.
- 3) Press the key (mA%/V) to select the input to be set in 'mA' or 'mA%' and the LCD displays unit 'mA' or 'mA %' in which the value of 0% denotes 4mA and the value of 100% denotes 20mA.
- 4) The Instrument starts measurement, and the LCD displays 'ON' and the measured result simultaneously.
- 5) The refreshing rate of measurement result is twice every second. And the LCD displays 'OL' if the measured value exceeds the measuring range.

Measuring DC Voltage

- 1) Insert one end of the test lead into the V jack of the Instrument (INPUT) terminal and connect the other end to the output of the user's device as shown in Figure5-4;
- 2) Press the key (OUTPUT / IN) the LCD displays INPUT , and it denotes that the Instruments is in an input state.
- 3) Press the key (mA%V) to select V function, and the LCD displays unit 'V'
- 4) The Instrument start measurement, and the LCD displays 'ON' and the measured result simultaneously.
- 5) The refreshing rate of measurement result is twice every second. And the LCD displays 'OL' if the measured value exceeds the measuring range.





Figure 5-4

Providing 24V Power Supply for Measuring Loop Current

Insert the test lead into the +LOOP and mA input jacks of the input terminal (INPUT) of the Instrument as shown in Figure5-5:
The key operation is the same as that of measuring the DC current.



Section Seven Setting Function

Fulfilling of the following operation will change the auto-power-off function of the Instrument.

In power-off state, press the keys (mA%V) and (power) simultaneously to power on, and release the (mA%V) key only after the LCD displays all the contents. The Instrument enters into the calibration mode. and the symbols 'AP-XX' appear in the LCD.

Press the key (▲) / (▼) and when the LCD displays 'AP'- OF ' the Instrument removes auto-power-off function; And when the LCD displays 'AP'- ON ' the Instrument removes auto-power-off function;

Press the key (100% / START) to store the selection; cut off the power again to exit from the maintenance function.

Section Eight Performance Index

Output	Range	Output Range	Resolution	Accuracy	Remark
DCV	20mA	0.000~22.000mA	0.001mA	±0.05%set value ±4uV	Max. load 1 KΩ at 20mA
Simu-transmitter (absorption current)	-20mA	0.000~22.000mA	0.001mA	±0.05%set value ±4uV	Max. load 1 KΩ at 20mA
Loop Power Supply	24V			±10%	Max output current up to 25mA

Input	Range	Output Range	Resolution	Accuracy	Remark
Voltage	28V	-0.200~28.000V	1mV	±0.025% reading ±2mV	Input resistance about 1MΩ
Current	20mA	-1.000~22.000mA	0.001mA	±0.02% reading ±4uA	resistance about 20Ω
Loop Current	20mA	0.000~22.000mA	0.001mA	±10%	providing 24V loop power

General Specification

Power Supply : 2 1.5V alkaline batteries (Lr6)

Battery life : about 400mA/3V under the condition of 10mA with 1KΩ load

Max permitted voltage : 30V (between any two terminal or between any terminal and earth ground)

Operating temperature : 0°C to 50°C

Operating relative humidity : ≤80% RH

Storage temperature : ≤-10°C to 50°C

Relative humidity for storage : ≤ 90%RH

Temperature co-efficiency : 0.1 x (designated accuracy) %/°C (5°C~18°C 28°C~40°C)

Size : 180(L) X 90 (W) X 47 (D) mm (with holster)

Weight : 500g (with holster)

Accessories : Operation instruction, a set of CF-36 industrial test lead (with alligator clips attached to probes)

Safety : Certified as compliant to IES 1010 Provision (Safety standard issued by International Electrotechnical Commission)

Section Nine Calibration

⚠ Note

• Calibration : In order to keep the designed accuracy of this Instrument. it is recommendable to calibrate your calibrator once a year. The following example show the use of recommended standard equipment to perform the calibration.

⚠ Caution

• Usage : Never apply more than the max permitted voltage to the input of the calibrator, otherwise the over voltage will lead to possible damage to the input section.

• Usage: during the operation, avoid short circuit and never apply more than the max .permitted voltage to the output of the Instrument or to a co-working standard device, otherwise any mal-operation will cause possible damage to their internal circuits.

Selecting Standard Equipment

Table 10-1

Calibration Item	Standard Equipment	output Range	Accuracy	Recommended	
Output	DCA 20mA	Digit meter	MAX 22mA	± (50ppm +0.4uA)	Digit meter KEITHLEY 2000 Standard resistance BZ10-100Ω
Measurement	DCA 20mA	Standard source	MAX 33mA	± (100ppm +0.2uA)	5520(FLUKE) or equivalent
	DCV 26V	Standard source	MAX 33V	± (12ppm +15uV)	

Ambient Condition for Calibration

Ambient temperature : **23°C±1°C ;**
 Relative humidity : **45 to 75% RH;**
 Preheating : **standard instrument should be preheated to specified time;**

put this Instrument in calibration environment for 24 hours, then power, and set it in non auto power off state, and preheat for half an hour.

⚠ Note

Power supply for calibrator; during the calibration, it is recommendable to use 2 1.5V (Lr6) batteries.

Operating Output Calibration

Operating calibration in order of items and calibration points listed in Table 10-2,

Item No.	Output Range	Calibration Point
1	DCA/20mA	0
		0 FS
		FS

1) In power-off state, press the keys (OUTPUT / INPUT) and (power) simultaneously to power on, and release the (OUTPUT / INPUT) key only after the LCD displays all the contents. The Instrument enters into the calibration mode, and the symbols 'CAL 0' appear in the LCD.

- 2) Press the key (OUTPUT/ INPUT) to select output function, and the LCD displays 'OUTPUT' 'mA';
- 3) Connect to the Instrument as shown in Figure 10-1;
- 4) Set the digital meter to an appropriate range;
- 5) When the output stabilized, press the key (▶) / (◀) and the key (▲) / (▼) to adjust the calibrator to a value in identity with the reading of the digit meter;
- 6) Press the key (100%/START), and the LCD displays 'SAVE' denoting that the calibrated point has been stored;




Figure 10-1

- 7) Press the key (STEP/AUTO) and the LCD displays 'CAL 0 FS'. With the output stabilized, repeat the operation of steps 5 and 6;
- 8) Press the key (STEP/AUTO) and the LCD displays 'CAL 0 FS'. With the output stabilized, repeat the operation of steps 5 and 6.

Operating Input Calibration

Operating calibrations in order of items and calibration points in Table 10-3;

Item No	Input Range	Calibration Point
1	DCA/20mA	0 : 00.000mA
		FS : 19.000mA
2	DCV/28V	0 : 00.000V
		FS : 19.000V

Current Measurement Calibration

- 1) In power-off state, press the keys (OUTPUT/INPUT) and (power) simultaneously to power on, and release the (OUTPUT/INPUT) key only after the LCD displays all the contents. The Instrument enters into the calibration mode, and the symbols 'CAL 0' appear in the LCD.
- 2) Press the (OUTPUT/INPUT) key to select measurement function, and the LCD displays 'INPUT' 'mA'
- 3) Connect to the Instrument as shown in Figure 10-2,




Figure 10-2

- 4) Set the Standard source to an appropriate range;
- 5) Set the output of standard source as the value given in Table 10-3 and when the output stabilized, press the (100%/START) key and the LCD displays 'SAVE' denoting that the calibrated point has been stored.
- 6) Press the key (STEP/AUTO) and the LCD displays 'CAL FS', and repeat the operation of steps 5

Voltage Measurement Calibration

- 1) Press the key (mA % / V) to select voltage measurement function , and the LCD displays 'INPUT' 'CAL' 0 V;
- 2) Connect to the Instrument as shown in Figure 10-3;
- 3) Set the standard source to an appropriate range.
- 4) Set the output of standard source as the value given in Table 10-3 and when the output stabilized, press the key (100%/START), and the LCD displays 'SAVE' denoting that the calibrated point has been stored.




Figure 10-3

- 5) Press the key (STEP/AUTO) and the LCD displays 'CAL FS', and repeat the operation of steps 4.

Section Ten Notice of the Manual

- The present operation instruction is subject to change without notice.
- The content of the operation instruction is regarded as correct Whenever any user find its mistakes, omission etc.,he or she is requested to contact the manufacturer;
- The present manufacture is not liable for any accident and hazard arising from the customer misuse or inadvertent operation;
- The function described in this operation instruction should not be used as ground as apply this product to a particular purpose.



MUMBAI

TEST CERTIFICATE

LOOP CALIBRATOR

This Test Certificate warrants that the product has been inspected and tested in accordance with the published specifications.

The instrument has been calibrated by using equipment which has already been calibrated to standards traceable to national standards.

MODEL NO. **KM-CAL 805**

SERIAL NO. _____

DATE: _____

**ISO 9001
REGISTERED**



WARRANTY

Each "KUSAM-MECO" product is warranted to be free from defects in material and workmanship under normal use & service. The warranty period is one year (12 months) and begins from the date of despatch of goods. In case any defect occurs in functioning of the instrument, under proper use, within the warranty period, the same will be rectified by us free of charges, provided the to and fro freight charges are borne by you.

This warranty extends only to the original buyer or end-user customer of a "KUSAM-MECO" authorized dealer.

This warranty does not apply for damaged Ic's, fuses, burnt PCB's, disposable batteries, carrying case, test leads, or to any product which in "KUSAM-MECO's" opinion, has been misused, altered, neglected, contaminated or damaged by accident or abnormal conditions of operation or handling.

"KUSAM-MECO" authorized dealer shall extend this warranty on new and unused products to end-user customers only but have no authority to extend a greater or different warranty on behalf of "KUSAM-MECO".

"KUSAM-MECO's" warranty obligation is limited, at option, free of charge repair, or replacement of a defective product which is returned to a "KUSAM-MECO" authorized service center within the warranty period.

THIS WARRANTY IS BUYER'S SOLE AND EXCLUSIVE REMEDY AND IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. "KUSAM-MECO" SHALL NOT BE LIABLE FOR ANY SPECIAL, INDIRECT, INCIDENTAL OR CONSEQUENTIAL DAMAGES OR LOSSES, INCLUDING LOSS OF DATA, ARISING FROM ANY CAUSE WHATSOEVER.